

### **Radiator grille 1st version**

#### **Removal**

---

- 1 Remove radiator grille (88—401) and pull out trim strip in lateral direction.

#### **Installation**

---

- 2 For installation proceed vice versa.


**Note:** Make sure that during installation of radiator grille the trim strips are not damaged.

### **Radiator grille 2nd version**

#### **Removal**

---

- 1 Lift damaged trim strip with plastic wedge or the like from cam and remove.



- 2 Cut off cam.

#### **Installation**

---

- 3 Install new trim strip with plastic clips.

